



Exchange arm for Tork H11 Please use all of your H11 refills prior transitioning to the H1 system, as H11 refills will not fit in H1 System dispensers


1




4



2



5



3

