Tork 2-Roll Side-by-Side CBT Dispenser:
T24 System: 59TR (smoke)

Conventional Bath Tissue Product Options:
Compatible with all Tork T24 Refills

Dispenser Specifications:

Dispenser Size	Outer Case Size	SCC Code	Case Weight	Case Cube	Pallet Configuration (ti x hi)
12.75" x 5.75" x 8.25"	12.75 x 6.75 x 8.75	10073286622447	2.19	0.36	21 x 9 = 189 units

Essity Internal

INSTALLATION INSTRUCTIONS

The user is responsible for the proper installation and use of this dispenser. **NOTE:** Hardware is not included with your product.

Equipment needed:

- Measuring tape
- Level
- Drill
- Drill bit suitable for appropriate wall mounting hardware.
- Screwdriver
- Pencil
- Eye protection
- Assemble appropriate fastners (screws, bolts, anchors, washers, etc.) for mounting.

1. Determine position on wall/surface with unit open. Through the holes at the back of the unit, use pencil to mark the spots where the drilling will be necessary. Try to mark spots as close as possible to the outer edges.

2. Drill the marked spots on the wall/surface with drill bit.

3. Complete the installation. Be sure to use fasteners (and anchors) in all mounting holes that are appropriate for the wall/surface to which the dispenser will be mounted. Use hardware included with the unit if it was factory supplied. The installation should be done with a flat washer between the head of the fastener and the inside back of the dispenser.



59TR

Mounting height
The lower part of the dispenser should be 27.5 inches 70 cm from the floor.

Essity Internal

59TR Loading Instructions

1. To fill dispenser after mounting: Insert key in slot on top of unit and push down. Cover will open forward. Insert right roll of tissue. Ensure access door covers right side roll. Insert left roll of tissue. Full roll of tissue will hold access door in place. Close cover.

2. When left roll is empty, slide access door in direction of arrow to access the right tissue roll.

3. To replenish rolls: Open cover. If there is still paper on the right roll, slide access door to the right side. Relocate partial roll to left side. Place new roll on right mandrel. Close cover.

Preventive Maintenance

The 59TR should be cleaned any time there is heavy paper dust build-up inside the dispenser. If paper dust is not a problem, approximately every year is a good frequency for cleanings. The following is the recommended procedure to cleaning:

1) Open the dispenser and remove the rolls of paper.

2) Clean out any paper dust. This can be done is several ways, such as, vacuuming, blowing out with a can of compressed air (wear safety glasses), wiping out with a damp cloth, etc.

3) Clean the cover with a general all-purpose cleaner that is safe for plastics.

Contacting Essity

To contact the Essity Quality Coordinator, dial 1-866-722-8675 and press option 6. If asked for the date code on the dispenser, see instructions above.

Essity Internal

59TR Mounting Outline Specifications



MOUNTING HOLE INFORMATION

(NOTE: COVER REMOVED FOR CLARITY)

Essity Internal